

Fitting



To fit the blind, slip the tab on the top rail of the blind in between the glass and the rubber gasket. Again, you can use washing up liquid or furniture polish to make the procedure easier and to avoid damaging your window.



Push the tab of the top rail up on the other side.



Repeat with the tab on the left and right of the bottom rail.



The blind is now ready to use as it is supplied pre-tensioned by the factory

CrosbyBlinds measure & Fit V2020